



10-Number Memory Two-Line Telephone User's Guide

29480

INTERFERENCE INFORMATION
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

HEARING AID COMPATIBILITY

This telephone system meets FCC standards for Hearing Aid Compatibility.


US NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM



BEFORE YOU BEGIN

PARTS CHECKLIST

Make sure your package includes the following items:



MODULAR JACK REQUIREMENTS

To properly connect your phone to your telephone lines, you should identify the type of wall jack(s) you have. You will need an RJ11C (for a single line) or a RJ14C (for two lines) type modular phone jack, which might look like the one pictured here. If you don't have either modular jack, call your local phone company to find out how to get one installed.

CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the IMPORTANT SAFETY INSTRUCTIONS provided with this product and save them for future reference.


INSTALLATION & SETUP

IMPORTANT INSTALLATION INFORMATION

- Never install telephone wiring during a lightning storm.
- Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.

DESKTOP INSTALLATION

Your two-line phone should be placed on a level surface such as a tabletop or desk.



Connecting Lines 1+2 to One Dual-Line Phone Jack

- Connect one end of either straight telephone line cord to the jack marked LINE 1+2 on the back of the base.

Connecting Lines 1+2 to Two Single-Line Wall Jacks

- Connect one end of either straight telephone line cord to the jack marked LINE 1+2 on the back of the base.

- Connect the other end of the straight white telephone line cord to a dual-line wall jack.

NOTE: If you connect the telephone line cord to a single-line (RJ11C) wall phone jack, you will only be able to use one telephone line (either LINE 1 or LINE 2) but not both lines simultaneously.

- Connect one end of the coiled handset cord to the jack on the side of the base and connect the other end to the jack at the bottom of the handset, then place the handset in the cradle.
- Set the RINGER 1 and RINGER 2 volume switches to the desired listening level (HI, LO or OFF).

NOTE: When in OFF position that line will not ring. Your telephone has separate and distinct ringer sounds for each line this will allow you to determine (audibly) the line of an incoming call.

- Set the mode switch to TONE. If you have problems dialing switch to PULSE.

Connecting Lines 1+2 to Two Single-Line Wall Jacks

In desktop or wallmount mode, you may want to wrap the excess telephone line cord around the mounting bracket on the bottom of the base.

NOTE: For best results, use a short line cord (not included), which can be purchased at most electronics specialty stores or department stores.

WRAPPING THE TELEPHONE LINE CORD

In desktop or wallmount mode, you may want to wrap the excess telephone line cord around the mounting bracket on the bottom of the base.

NOTE: For best results, use a short line cord (not included), which can be purchased at most electronics specialty stores or department stores.

TELEPHONE BASICS

MAKING AND RECEIVING CALLS

CHOOSE A LINE

Press LINE 1 or LINE 2.

NOTE: You can use the telephone if you have only one incoming line. However you cannot access a second line.


REDIAL

Use REDIAL, to quickly redial the last number that was manually dialed. This is useful when a line is busy for a long time.

- Pick up the handset.
- Wait for dial tone.
- Press the REDIAL button. The phone automatically redials the last number that was dialed (up to 32 digits).

WALL MOUNT INSTALLATION

Your telephone can also be mounted on a wall plate (not included).



Connecting Lines 1+2 to One Dual-Line Phone Jack

- Connect one end of either straight telephone line cord to the jack marked LINE 1+2 on the back of the base.
- Connect the other end of the straight white telephone line cord to a dual-line wall jack.

NOTE: If you connect the telephone line cord to a single-line (RJ11C) wall phone jack, you will only be able to use one telephone line (either LINE 1 or LINE 2) but not both lines simultaneously.

- Slip the mounting holes on the base over the wall plate posts and firmly slide the unit down into place (wall plate not included).
- Connect one end of the coiled handset cord to the jack on the side of the base and connect the other end to the jack at the bottom of the handset, then place the handset in the cradle.
- Set the RINGER 1 and RINGER 2 volume switches to the desired listening level (HI, LO or OFF).


CONFERENCE

The conference feature enables you to carry on three-way conversation using LINES 1 and 2 simultaneously.

- Place first party on HOLD.
- Press the alternate LINE.
- Dial phone number for second party.
- Press CONF and talk to both parties.
- When finished with conference press LINE 1 or 2 to talk privately and disconnect other line.
- When finished hang up.

VOLUME

The volume controls for the handset and line ringers are separate on this phone so you can adjust one without affecting the others.



To adjust the handset volume, use the VOL ● ● ● switch on the left side of the phone.

To adjust RINGER 1 and RINGER 2 volumes, use the switches on the left side of the base unit. To select volume for RINGER use ▲ ● ● ● OFF. Note that, if in the OFF position, that line will not ring. Your telephone has separate and distinct ringer sounds for each line allowing you to determine (audibly) the line of an incoming call.

TEMPORARY TONE FEATURE

If you have Pulse (rotary) service, and want to access customer calling services that require tone dialing, such as getting information from a local bank, you can use this feature.

- Press the TONE BUTTON (*) after you have connected to the service to enable Tone dialing.
- When you hang up, the phone automatically returns to Pulse dialing mode.

To Make a Call

To Receive a Call

- Pick up the handset.
- Press LINE 1 or LINE 2.
- Replace the handset to hang up.
- Press the TONE/PULSE switch. If in PULSE position, set to TONE, then hang up and dial again.

Both line buttons are down and both lines are active (a dial tone can be heard).

Press Line 1 or Line 2 to select the line you want to use. The other line button releases.

MEMORY

Store as many as 10 numbers in memory for easy dialing. Each of the memory buttons is capable of storing phone numbers that are up to 16 digits.

STORING A NUMBER IN MEMORY

- Pick up the handset.
- Select line 1 or 2, and wait for a dial tone.
- Press STORE button.

4. Enter the telephone number to be stored.

5. Press STORE button.

6. Press the desired memory location button (0-9 on the keypad).

7. Replace the handset.

8. To store another number repeat steps 1-7.

INSERTING A PAUSE IN THE DIALING SEQUENCE

Press the REDIAL button to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example after you dial 9 for an outside line, or to wait for a computer access tone). Each pause counts as 1 digit in the dialing sequence.

CHANGING A STORED NUMBER

To change a stored number, you just replace it with a different number using the procedure for storing a number.

DIALING A STORED NUMBER

- Pick up the handset.
- Press the line you want (line 1 or line 2).

3. Wait for a dial tone.

4. Press MEM DIAL button.

5. Press memory address button 1-9.

NOTE: If you make a mistake while storing a number, hang up and repeat the storing procedure.

GENERAL PRODUCT CARE

To keep your Telephone working and looking good, follow these guidelines:

- Avoid putting it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping the unit and/or other rough treatment.
- Clean with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship it at a later date.

SERVICE

This product may be serviced only by the manufacturer or its authorized service agents. Changes or modifications not expressly approved by ATLINKS USA, Inc. could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this guide or call customer service at 1-800-448-0329.

Or refer inquiries to:

ATLINKS USA, Inc.
Manager, Consumer Relations
P O Box 1976
Indianapolis, IN 46206

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date _____

Name of store _____

TROUBLESHOOTING TIPS

Problem

Solution

No dial tone.

- Check hook switch to make sure it pops up.
- Check if a LINE button depressed.

Phone dials in pulse with tone service

- Make sure TONE/PULSE switch is set to TONE
- Make sure TONE/PULSE switch is set to PULSE

Phone doesn't ring

- Check RINGER VOLUME.
- You might have too many phones on one line.

Can't be heard by other party

- Make sure phone line is connected properly.
- Make sure other phones are not OFF hook at the same time. If so, this is normal condition as volume drops when additional phones are used at once.

Memory dialing

- Make sure you entered numbers correctly. (See "Memory.")

Indicator lights do not

- Check all of the phones on this line.
- Turn on or off properly

While dialing with Tone Service, the phone makes clicking sounds and line indicators (lights) flicker on and off.

- Check the Tone/Pulse switch. If in PULSE position, set to TONE, then hang up and dial again.

Both line buttons are down and both lines are active (a dial tone can be heard).

Press Line 1 or Line 2 to select the line you want to use. The other line button releases.

LIMITED WARRANTY

What your warranty covers:

- Defects in materials or workmanship.
- One year, from date of purchase.

(The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

What we will do:

- Provide you with a new or, at our option, a refurbished unit. The exchange unit is under warranty for the remainder of the original product's warranty period.
- Properly pack your unit. Include any cables, etc., which were originally provided with the product.
- "Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the product is within the warranty period, must be presented to obtain warranty service." For rental firms, proof of first rental is also required. Also print your name and address and a description of the defect. Send via standard UPS or its equivalent to:

ATLINKS USA, Inc.

c/o Thomson
11721 B Alameda Ave.
Socorro, Texas 79927

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
- Insure your shipment for loss or damage. ATLINKS accepts no liability in case of damage or loss.

A new or

